




CABINET PARTS

REFRIGERATOR

For Models: ET1CHKXKQ01, ET1CHKXKT01, ET1CHKXKB01
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: ET1CHKXKQ01, ET1CHKXKT01, ET1CHKXKB01
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT2213196	Service & Wiring Sheet
	LIT2218460	Energy Label
	LIT2212841	Use & Care Guide

Following May Be Purchased


DO-IT-YOURSELF REPAIR MANUALS

	LIT677969	Do-It-Yourself Manual/Ref./Frz.
2	2189410	Hinge (Top)
3	2166108	Roller-Front (2)
5	489385	Clamp, Tube (Water Supply Line)
10	2179826	Rivet
11	3400504	Screw
12	549193	Clamp-Cord
15	489497	Screw
16	2183972	Hinge, Center
17	2183854	Shim, Hinge Center
18	8281265	Screw
20	2189194	Hinge Butt
23	2172743	Shim, Bottom Hinge
24		Fitting, Water Tube (Not Serviced)
27		Hole Plug (6)
	2201012	White
	2200924	Biscuit
	2183998	Black
35		Corner Filler (2)
	2201014	White
	2200926	Biscuit
	2201017	Black
36		Grille
	2201006	White
	2201020	Biscuit
	2201008	Black
37	489341	Washer
38	487576	Washer
39	2189356	Clip-Grille
40		Cover-Hinge
	2213360	White
	2213364	Biscuit
	2213363	Black
41		Rail, Center (Not Serviced)
42	489464	Screw
44	2202884	Cover, Unit
45		Cabinet (Not A Serviceable Part)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: ET1CHKXKQ01, ET1CHKXKT01, ET1CHKXKB01
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS


For Models: ET1CHKXKQ01, ET1CHKXKT01, ET1CHKXKB01
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes #9 & #22)	13		Nameplate	25	2204812	Bin, Door Shelf
	2183920	White		2175383	White	26	2189202	Bracket, Door Stop (2)
	2205284	Biscuit		2205769	Biscuit	27	488921	Screw
	2200714	Black		2200944	Black	28		Hole Plug
2		Handle, Trim	16	2195378	Trim, Door Shelf		2212648	White
	2193353W	White	19		Freezer Door (Includes #22 & #23)		2212649	Biscuit
	2193353T	Biscuit		2182489	White		2212651	Black
	2193353B	Black		2204686	Biscuit	29	2156007	Plug-Trim
5		Handle Center		2200711	Black	30	2156006	Plug-Trim
	2213112W	White	20		Hole Plug	31	2218118	Compartment Door Handle, F.C.
	2213112T	Biscuit		2189000	White	33	2213111W	White
	2213112B	Black		2200936	Biscuit		2213111T	Biscuit
6	489357	Screw		2189009	Black		2213111B	Black
8	8281206	Screw	21	2188236	Door, Flip-Up	37	2195947	Trim-Door (2)
9		Door Gasket, Magnetic	22	2183003	Thimble	41	2195916	Endcap (4)
	2202875	Mist Beige	23		Door Gasket, Magnetic	42	2195948	Trim, Door
	2202882	Black		2214967	Mist Beige			
				2214969	Black			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LINER PARTS

For Models: ET1CHKXKQ01, ET1CHKXKT01, ET1CHKXKB01
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LINER PARTS

For Models: ET1CHKXKQ01, ET1CHKXKT01, ET1CHKXKB01
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	531933	Grommet (2)
3	2221653	Gasket, Evaporator Cover (2)
4	2213473	Adaptive Defrost Control
5	2212485	Barrier, Tube
6	941839	Hole Plug
7	2187352	Wire Assembly, Control Box
8	2162085	Socket, Light (2)
9	2179858	Damper, Air
10	2183833	Motor, Fan
11	2163777	Blade, Fan
12	2212982	Control Box
13	2200859	Thermostat Assy. (Includes Items 5, 18)
14	489478	Screw
15	489412	Screw
16	2201175	Cover, Evaporator
17	527949	Light Bulb (2)
18	2200831	Weight, Thermal
19	1118894	Switch, Rocker Arm
20	2179859	Post, Damper
21	2176281	Cover, Air Diffuser
22	2200863	Knob, Thermostat
23	2182340	Air Tower
24	2189452	Air Diffuser, Bottom
25	2184617	Freezer Floor
26	2204690	Air Diffuser, Top
27	2205003	Cover, Inlet Tube
29	2200641	Bracket, Fan Motor
32	487996	Cap
33	98129	Screw (2) 6-20 x 1 1/16
34	2176297	Knob, Damper
35	2163810	Bracket, Damper Knob
36	2205079	Seal, Rear Thermostat
38	2171931	Valve, Release
39	2187295	Wire Assembly, Freezer Compartment
45	2204639	Shield, Heat

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

For Models: ET1CHKXKQ01, ET1CHKXKT01, ET1CHKXKB01
(White) (Biscuit) (Black)

This exploded view diagram illustrates the assembly of a washing machine. The components are numbered as follows:

- 1**: Main front panel/frame.
- 2**: Screws for the top panel.
- 3**: Heating element assembly.
- 4**: Water inlet hose with filter.
- 5**: Water inlet valve solenoid.
- 6**: Water inlet valve connector.
- 7**: Top panel.
- 8**: Drain pump motor.
- 9**: Drain pump impeller.
- 10**: Drain pump housing.
- 11**: Detergent dispenser drawer.
- 12**: Detergent dispenser drawer assembly.
- 13**: Detergent dispenser drawer connector.
- 14**: Water level sensor.
- 15**: Water level sensor connector.
- 16**: Water level sensor float.
- 17**: Drum support roller.
- 18**: Drum support roller pin.
- 19**: Drum support roller bracket.
- 20**: Drum support roller assembly.
- 21**: Drum support roller assembly (dashed line).
- 22**: Drum support roller assembly (dashed line).
- 23**: Drum support roller assembly (dashed line).
- 24**: Drum support roller assembly (dashed line).
- 25**: Drum support roller assembly (dashed line).
- 26**: Drum support roller assembly (dashed line).
- 27**: Drum support roller assembly (dashed line).
- 28**: Drum support roller assembly (dashed line).
- 29**: Drum support roller assembly (dashed line).
- 30**: Drum support roller assembly (dashed line).
- 31**: Drum support roller assembly (dashed line).
- 32**: Drum support roller assembly (dashed line).
- 33**: Drum support roller assembly (dashed line).
- 34**: Drum support roller assembly (dashed line).
- 35**: Drum support roller assembly (dashed line).
- 36**: Drum support roller assembly (dashed line).
- 37**: Drum support roller assembly (dashed line).
- 38**: Drum support roller assembly (dashed line).
- 39**: Drum support roller assembly (dashed line).
- 40**: Drum support roller assembly (dashed line).
- 41**: Drum support roller assembly (dashed line).
- 42**: Drum support roller assembly (dashed line).
- 43**: Drum support roller assembly (dashed line).
- 44**: Drum support roller assembly (dashed line).
- 45**: Drum support roller assembly (dashed line).
- 46**: Drum support roller assembly (dashed line).
- 47**: Drum support roller assembly (dashed line).
- 48**: Drum support roller assembly (dashed line).
- 49**: Drum support roller assembly (dashed line).
- 50**: Drum support roller assembly (dashed line).
- 51**: Drum support roller assembly (dashed line).
- 52**: Drum support roller assembly (dashed line).
- 53**: Drum support roller assembly (dashed line).
- 54**: Drum support roller assembly (dashed line).
- 55**: Drum support roller assembly (dashed line).
- 56**: Drum support roller assembly (dashed line).
- 57**: Drum support roller assembly (dashed line).
- 58**: Drum support roller assembly (dashed line).

7

UNIT PARTS

For Models: ET1CHKXKQ01, ET1CHKXKT01, ET1CHKXKB01
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	2205340	Plate, Unit Mounting	17	2150304	Roller (2)	Following Parts Not Illustrated and Optional Parts Not Included		
2	489478	Screw	18	981126	Rivet			
3	2212599	Condenser	19	2182338	Clip, Heater			
4	2166124	Heater, Defrost	20	489373	Screw			
5	2195390	Evaporator Assy.	22		Capacitor			
6	489494	Screw		2169373	Production			
7	2172620	Drain Pan		4387764	Service			
8	2182380	Defrost Bi-Metal	23	2166683	Clip, Capacitor			
9	2176301	Bracket, Heater	24	488687	Screw			
10	2163780	Extension, Air Baffle	27	3400518	Screw			
11	2212998	Strap	28	2218376	Compressor (Includes Items 12, 13, 15, 22, 27 and 29)			
12	4387731	Cover, Terminal (Service Only)						
13		Overload	29	2199167	Drier			
	4387766	Service (Includes Relay)	30	2155774	Clamp			
14		Grommet (4)	39	2198921	Air Baffle			
	1100826	Production	40	2188537	Motor, Condenser			
	4387558	Service	42	2187384	Wire Assembly, Unit			
15	2212964	Start-Device Combination (Start Relay and Overload for Production Compressor Only)	43	2190685	Blade, Fan			
16	2201185	Block, Support	44	486692	Nut			
			45	2212603	Tube, Transition			
			46	2205294	Tube, Discharge			
			47	2205293	Tube, Suction			
			48	2212848	Tube, Process			
			56	488500	Screw			
			58	2210451	Tray, Evaporator			

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE


4.0 Ozs.
(R134A)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SHELF PARTS

For Models: ET1CHKXKQ01, ET1CHKXKT01, ET1CHKXKB01
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2210522	Shelf, Ladder (2)
2	2202821	Shelf, Ladder Center
3	2163762	Cup, Shelf Mtg.
5	489478	Screw
6	2216624	Egg Bin
7	2176222	Slide, Humidity Control
8	2212446	Body, Humidity Control
9	2210526	Cover, Crisper
10	2201102E	Shelf, Cantilever
11	2176225	Insert, Crisper Cover
12	2201106	Pan, Shelf Cantilever
13	2200987	Glass, Shelf
14	2188526	Trim, Shelf Front
15	2163832	Crisper Support
16	2188521	Trim, Shelf Rear
17	2184667	Shelf, Freezer
20	2218132K	Pan, Meat
21	2188517	Trim, Shelf Side
22	841180	Ice Tray (2)
24	2218141	Crisper Pan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LITERATURE AND OPTIONAL PARTS

For Models: ET1CHKXKQ01, ET1CHKXKT01, ET1CHKXKB01
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and Optional Parts (Not Included)		
		Insulation, Fiberglass (63-1/2" x 35-1/2" x 2-5/8")
212643		Sealer, Gum (4 Feet)
479502		Tape, Vinyl (3/4" x 108")
876305		Kit, Insulation (14 Pcs. 3" x 24" x 48")
876370		Kit, Insulation (2 Pcs. 3" x 24" x 48")
876029		Kit, Foam Slab (30" x 32-1/2" x 1-1/2")
505587		Sealer, Mastic (1 Qt.)
511873		Touch-Up, White Porcelain (2 Oz.)
542638		Grease, Silicone (1/2 Oz.)
542639		Cement, Alumilastic (1-1/4 Oz.)
606755		Bag, Insulation (36-5/8" x 46")
799833		Kit, Evaporator Repair (Aluminum Epoxy)
799832		Kit, Porcelain Repair (White)
503695		Cork Sealer (1/4 Pound)

Illus. No.	Part No.	DESCRIPTION
Customer Touch-Up Material		
	*350942	Primer, White (12 Oz. Spray Can)
	*350939	Enamel, Black (12 Oz. Spray Can)
	*350930	Enamel, White (12 Oz. Spray Can)
	*4392901	Enamel, Biscuit (12 Oz. Spray Can)
	72017	Brush Touch-Up Kit (White)
	72032	Brush Touch-Up Kit (Black)
	4392899	Brush Touch-Up Kit (Biscuit)
Refinishing Material		
	799344	Enamel, White (1 Qt. Uncut)
	4392900	Enamel, Biscuit (1 Qt. Uncut)
	786032	Enamel, Black (1 Qt. Uncut)
	833938	Kit, Terminal Connector
<p>*Caution: The spray paint is not to be used where the paint may make contact with the door gaskets.</p>		
ICE MAKER FIELD INSTALLABLE		
	2155469	ECKMF94
TORX SCREW WRENCH		
	1117510	Torx Key

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST